

LapCool5

NOTEBOOK COOLER



Rubber Feet 70 mm FANS Rubber Feet



USB mini-B USB Hub

Package Contents

LapCool 5
USB mini-B Cable
USB 5V Power Cable

Using the LapCool 5

Place the LapCool 5 on a stable, flat surface. Place the rear of notebook on the LapCool 5 and position it so that it sits stably.

Powering the LapCool 5

The LapCool 5 can be powered by either the USB mini-B cable or the USB 5V Power Cable. Connect either cable to the LapCool 5 and then connect the USB-A end to your computer. If the fans do not start spinning, make sure the fan control knob is not in the OFF position.